



**nickelodeon™**  
**TEENAGE MUTANT NINJA**  
**TURTLES™**


**NINJA ACTION**  
**NINJA STRIKIN'**  
**MIKEY**

- 1.** Wind up clockwise, as shown, until dial can no longer turn.



- 2.** Set figure down, press down on Turtle head to activate Ninja Action!

**Ninja Action!**



**360°**  
**Spinning**  
**Body!**

Ages 4 and up  
 Asst. #91620  
 Item #91640

\* Works best on hard, flat surfaces.



©2014 Viacom International Inc. All Rights Reserved. Nickelodeon, TEENAGE MUTANT NINJA TURTLES and all related titles, logos and characters are trademarks of Viacom International Inc. ©2014 Viacom Overseas Holdings C.V. All Rights Reserved. Nickelodeon, TEENAGE MUTANT NINJA TURTLES and all related titles, logos and characters are trademarks of Viacom Overseas Holdings C.V. ©2014 Playmates. Playmates International Company Ltd. 23/F, The Toy House, 100 Canton Road, TST, Kowloon, Hong Kong. PRINTED IN CHINA.

For more detailed instructions visit  
[www.Playmatestoys.com](http://www.Playmatestoys.com)