


TEENAGE MUTANT NINJA TURTLES

Kids.
follow these
simple blueprints,
it's easy!



ASSEMBLY

1. Plug main wings (2) and tail wings (2) to Bubble Bomber body as shown.
2. Snap sai-styled vertical stabilizers (2) to rear upper deck of Bubble Bomber as indicated.
3. Snap detachable buzz bombs (2) to main wings as shown.
4. Plug kowabunga corkscrew nose cone to front of Bubble Bomber.
5. Apply all-American Turtle labels 1-24 as shown.

DIRECTIONS To Prepare The Bodacious Bubble Bomber For Its Strategic Smoke Bombing Run:

1. Insert 3 "AA" alkaline batteries as indicated in diagram A.
2. Open the cool clear ninja-styled cockpit. Lift the cap from the oil intake reservoir and fill with the non-toxic smoke bomb oil between the two lines. See diagram B. Do not fill past the top line. If you mistakenly overfill the reservoir, soak up excess oil by inserting a thinly rolled piece of paper towel.
3. Insert your favorite Turtle teen in the cockpit seat.
4. Press the lever on the bottom of the ninja sai handle in direction of arrow and pull down to release the bubble solution cartridge. See diagram C. Once cartridge is removed, fill with the Bodacious bubble solution (included). See diagram D. To avoid overflow, fill solution to 1/4" below the edge of the cartridge.
5. Insert bubble solution cartridge back into ninja sai handle. Make sure both hoses in sai handle are inserted through hole on top of cartridge. See diagram E.
6. Before turning your Bubble Bomber on, pump the Turtle trigger until you see bubble solution at the tip of the smoke bubble generator (approximately 20 pumps). Note: To cut pumping time, cover end of smoke bubble generator while pumping trigger.
7. Once there is bubble solution at the tip of the smoke bubble generator, turn the Bubble Bomber on, and watch smoke bubbles form (smoke will appear in bubbles after the first few bubbles are formed).
8. To drop smoke bubbles on the Foot, simply pull the Turtle trigger when the smoke bomb is the size you desire.

Note: Bubble Bomber smoke is non-toxic

CAUTIONS:

1. Toy is recommended for outdoor use only. If used indoors, bubble solution could stain carpet or furniture.
2. Check oil level after every 15 minutes of use. Oil level must be maintained between marked lines.
3. Do not turn Bubble Bomber upside down when removing bubble solution cartridge.
4. If smoke output seems to be too weak, check oil level. If oil level is adequate, replace batteries.
5. Do not play with Bubble Bomber in confined areas.
6. Do not turn Bubble Bomber on until bubble solution is seen at the tip of the smoke bubble generator. (See step 6)
7. Make sure oil reservoir cap is securely shut after filling reservoir.
8. To avoid excess leakage of bubble solution from the nozzle, do not press the trigger too rapidly.
9. It is normal for small drops of solution to drip out from nozzle after machine is turned off.
10. Bubble solution is not intended for human consumption.

BUBBLE SOLUTION:

When Bubble Solution runs out, replace with any standard Bubble Solution available at your nearest retail store.

Please be sure to keep the small plastic bottle. Fill the bottle with VEGETABLE OIL ONLY and use it to refill your Bubble Bomber, again and again.

AGES 4 & UP
STOCK NO. 5312

Playmates®